

AVerTouch

— **User Manual** —

Disclaimer

No warranty or representation, either expressed or implied, is made with respect to the contents of this documentation, its quality, performance, merchantability, or fitness for a particular purpose. Information presented in this documentation has been carefully checked for reliability; however, no responsibility is assumed for inaccuracies. The information contained in this documentation is subject to change without notice.

In no event will AVer Information Inc. be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use this product or documentation, even if advised of the possibility of such damages.

Trademarks

“AVer” is a trademark owned by AVer Information Inc. Other trademarks used herein for description purpose only belong to each of their companies.

Copyright

© 2025 AVer Information Inc. All rights reserved. | May 5, 2025

All rights of this object belong to AVer Information Inc. Reproduced or transmitted in any form or by any means without the prior written permission of AVer Information Inc. is prohibited. All information or specifications are subject to change without prior notice.

More Help

For FAQs, technical support, software and user manual download, please visit:

Non-USA

Download Center: <https://www.aver.com/download-center>

Technical Support: <https://www.aver.com/technical-support>

USA

Download Center: <https://www.averusa.com/education/support>

Technical Support: <https://averusa.force.com/support/s/contactsupport>

Contact Information

Headquarters

AVer Information Inc.
8F, No.157, Da-An Rd.,
Tucheng Dist., New Taipei City
23673, Taiwan
Tel: +886 (2) 2269 8535

USA Branch Office

AVer Information Inc.,
Americas
44061 Nobel Drive, Fremont,
CA 94538, USA
Tel: +1 (408) 263 3828
Toll-free: +1 (877) 528 7824

Europe Branch Office

AVer Information Europe B.V.
Westblaak 134, 3012 KM,
Rotterdam, The Netherlands
Tel: +31 (0) 10 7600 550

Japan Branch Office

アバー・インフォメーション
株式会社
〒160-0023 日本東京都新宿区
西新宿 3-2-26 立花新宿ビル 7
階
Tel: +81 (0) 3 5989 0290
お客様サポートセンター(固定電
話のみ): +81 (0) 120 008 382

Vietnam Branch Office

Công ty TNHH AVer
Information
(Việt Nam)
Tầng 5, 596 Nguyễn Đình
Chiểu, P.3, Quận 3, Thành
phố Hồ Chí Minh 700000, Việt
Nam
Tel: +84 (0) 28 22 539 211
Hỗ trợ kỹ thuật: +84 (0) 90 70
080 77

Korea Office

한국 에버 인포메이션 (주)
서울시 종로구 새문안로 92
(신문로 1가,
광화문오피시아빌딩) 1831,
1832 호
Tel: +82 (0) 2 722 8535

Contents

Overview	1
System Requirements	1
Install AVerTouch	1
Get Started.....	2
Cameras Page.....	2
Camera Card.....	4
Library Page	6
Windows.....	6
Mac.....	8
Account Page	10
Connect Your Document Camera.....	12
USB Connection	12
Wi-Fi Connection (supported AVer models)	13
Troubleshoot.....	14
IP Address Connection	17
Point-to-Point (P2P) Connection on Windows.....	17
Windows Hotspot.....	18
Connect Your Document Camera on iPadOS12	20
Upgrade Document Camera Firmware	21
Live View Interface.....	22
Toolbars	24
Bottom Toolbar	24
Right Toolbar	26
Split Screen and Fly-Out Media Library	28
Optical Character Recognition (OCR).....	30
AI Image Generator	32
Troubleshoot	36

Overview

System Requirements


- Windows 7, 10, 11
- macOS 13, 14, 15
- iPadOS 12

Install AVerTouch

1. Download AVerTouch from AVer Download Center. (<https://www.aver.com/download-center>).
2. Double-click the downloaded .exe file.
3. Follow the instructions displayed on the setup wizard to install AVerTouch.

Get Started

Cameras Page



1. Sync

Click to start camera discovery manually. Camera discovery is constantly running in the background.

2. Add camera

Add a camera by entering its IP address.

3. Favorite


Click to see your favorite Wi-Fi document cameras.

4. Filter


Select which cameras to display.

- In my classroom: Cameras that share your computer's Wi-Fi network.
- All cameras: Any camera that AVerTouch detects.

5. User menu



- Click **Log in** to log in to your Google account and use Google Drive and Google Classroom.
 1. Click **Log in** from the user menu > **Log in with Google**.
 2. Select checkboxes to allow AVerTouch access and click **Continue**.



Camera Card

Detected document cameras are represented by purple (USB and Wi-Fi mode) or white (access point (AP) mode) camera cards on the camera page.

All Cameras

3 Cameras detected

AVerVision M5



 **USB**

AVerM15W-5CF370597546



Connect your camera

 **AP mode**

AVerM15W-5CF3705DF9D4


Connect your camera

 **AP mode**



1. Camera name

Displays the document camera name.

2. Camera information

Displays document camera information such as the IP address.

3. Connection mode

Indicates your document camera mode.

4. Play button

Click to start live view.

5. Favorite (Wi-Fi document cameras)

Save a Wi-Fi document camera as favorite and see it when clicking the **Favorite** button on the upper right corner of the camera page.

6. Set up Wi-Fi connect


Click to use a USB cable to set up a Wi-Fi connection (supported models).

7. Speed Test

Perform a speed test in Wi-Fi mode to check your bandwidth. Select to lower the resolution or frame per second (FPS) when the connection speed is slow.

Library Page

Windows



Displays your default drive for saving images and videos. The default is:

- Guest: Local drive.
- Log in with Google: Google Drive.

To upload files to your Google Drive or YouTube account:

1. Select the file you want to upload in My Drive and click **Upload**.




2. Select Google Drive or YouTube. You will be asked to log in your Google account if you haven't already.

To delete files in My Drive or Google Drive:

1. Select the file you want to delete and click **Delete**.



Mac



1. My Drive

Displays your default drive for saving images and videos. The default is:

- Guest: Local drive.
- Log in with Google: G-Drive.

2. Library

- View all: Show files and folders.
- Files: Show only files.
- Folders: Show only folders.

3. Filters

- Recent: Show recently used files in the past 7 days.
- Favorite: Show favorite files and folders.

4. Sync

Click to refresh the local drive or Google Drive.

5. Open file location (Local drive only)

Click to open the default file location: `/Users/Username/Movie/AVer`

6. Set file location (Local drive only)


Click to set a new folder location.

7. Sort

Click the **Sort** button  to sort by date added or alphabetically.

To upload files to your Google Drive or YouTube account:


1. Select the file you want to upload in your local drive and click **Upload**.



2. Select Google Drive or YouTube. You will be asked to log in your Google account if you haven't already.

To rename, move or delete files in My Drive or Google Drive:

Select the **More options** button  on a file and click **Edit name**, **Move** or **Delete**.




To add files and folders to Favorite:

Click the **Star** button  on a file or folder in your local drive to add to **Favorite**.



Account Page



Account

Item	Description
Drives	Select your default drive for saving images and videos. The default is: <ul style="list-style-type: none"> • Guest: Local drive. • Log in with Google: Google Drive.

Support

Item	Description
Help Guide	Open AVerTouch user manual.
DocCam Tour	Take a quick tour of AVerTouch.

About

Item	Description
System Settings	<ul style="list-style-type: none"> • Usage Data: Opt-in to or opt-out of providing usage data. • Plug and Play USB Camera: Toggle on to automatically open live view when your document camera is connected to a computer via USB. • Auto Software Update: Toggle on to automatically check for updates.

	<ul style="list-style-type: none"> • Version: Displays current version. • Check for updates now: Click to check for updates now.
Languages	Select a preferred language.
Privacy Policy	View privacy policy.
Terms of Service	View terms of service.
OCR License	<p>Purchase and enter your license key to enable optical character recognition (OCR) function. Or unlink and transfer your license key to another computer.</p> <p>Note: Make sure your computer has internet when purchasing and activating your license.</p>


Connect Your Document Camera

You can connect your document camera via any of the following on AVerTouch:

- USB
- Wi-Fi
- IP address
- point-to-point (P2P) on Windows
- Windows hotspot

USB Connection


1. Connect your document camera to a computer with a USB cable.
2. Open AVerTouch. A purple camera card will be displayed.




3. Click the **Play** button  to start live view.

Wi-Fi Connection (supported AVer models)

1. Make sure your computer has Wi-Fi connection and your document camera supports Wi-Fi connection.
2. Open AVerTouch. A white camera card will be displayed when your document camera is detected.



3. The name will be "AVer model name – Wi-Fi dongle MAC address." MAC address is different for each device.
4. Click the **Connect** button .
5. Select your Wi-Fi network and enter the password in the **Connect to a Wi-Fi Network** dialog box. Click **Done**.



6. When your document camera is connected to the Wi-Fi network, a purple camera card will be displayed.
7. Click the **Play** button  to start live view.

Troubleshoot

Check your document camera's Wi-Fi status.

1. Make sure your document camera is in Wi-Fi mode by checking the Wi-Fi indicator. On AVer M15W, the indicator is solid blue.
 - If the indicator is off and the document camera is connected to the computer via a USB cable, it is in USB mode. Unplug the USB cable.

Switch your document camera to Wi-Fi mode on the OSD menu .

1. Connect your document camera to an HDMI display using an HDMI cable.
2. Use the buttons on your document camera to open the OSD menu.
3. Select **Wireless > Mode > Wi-Fi** on the OSD menu.


IMAGE	Mode	AP
WIRELESS	Miracast Setup	Wi-Fi ✓
SYSTEM		Miracast

Use a USB cable to set up a Wi-Fi connection (supported models).

1. Use a USB cable to connect a document camera to a computer. A purple camera card is displayed.




2. Click the **Wi-Fi setting** button  on the upper right corner and follow the instruction.
3. Select your Wi-Fi network and enter the password in the **Connect to a Wi-Fi Network** dialog box. Click **Done**.




4. When a **Set Wi-Fi successfully** dialog box is displayed, unplug the USB cable.
5. When your document camera is connected to the Wi-Fi network, a purple camera card will be displayed.
6. Click the **Play** button  to start live view.

Other places where you can use a USB cable to set up a Wi-Fi connection (supported models):


- Open live view > click the **Camera Settings** button  on the upper right corner > go to **Network** > click **Set up**.



- Click **USB connection** on the error message when you fail to set up Wi-Fi connection wirelessly.



- Click the **Camera information** button  on a USB mode camera card.



A red triangle button  in the Wi-Fi network field indicates that your document camera has failed to connect to the Wi-Fi network or it has connected to a Wi-Fi network different from that of your computer.

1. Click the red triangle button  to start setting up a Wi-Fi connection with a USB cable.
2. Or click **Enable AP Mode** to go from Wi-Fi mode to Access Point (AP) mode.

IP Address Connection

If your document camera and computer are connected to the same network, but the document camera isn't detected, connect by entering the IP address.


1. Connect your document camera to an HDMI display.
2. Use the buttons on your document camera to open the OSD menu.
3. Go to **System > Information** to look up the IP address.
4. Open AVerTouch. Click the **Add camera** button  on the upper right corner of the camera page.
5. Enter the IP address.

Point-to-Point (P2P) Connection on Windows


1. Plug your AVer Wi-Fi dongle (optional accessory) into your computer.
2. Make sure your document camera is in Wi-Fi mode by checking the Wi-Fi indicator. On AVer M15W, the indicator is solid blue.
3. Use the buttons on your document camera to open the OSD menu.
4. Select **Wireless > Mode > AP** on the OSD menu.



5. Open AVerTouch. A white camera card will be displayed when your document camera is detected.




6. Click the **Connect** button .
7. Enter your document camera name in the **Save Camera** dialog box. Click **Done**.




The image shows a "Save Camera" dialog box. The title is "Save Camera". Below the title, it says "Please set your camera name and password". There are three input fields: "Camera name" with the value "AVerVision M15W", "Camera passcode", and "Camera passcode (optional)". Below the input fields, there is a note: "Leave blank to keep default settings. You can come back and change this later if you want." At the bottom of the dialog box, there are two buttons: "Cancel" and "Done".

Windows Hotspot

- Make sure your computer is connected to the internet. For the best connectivity, we recommend a 2.4G Wi-Fi.
 - Network connection on your computer will be lost temporarily during document camera setup.
1. Turn on **Mobile hotspot**.
Select **Start** , then select **Settings**  > **Network & Internet** > **Mobile hotspot**.
 2. Turn off **Power saving** to prevent mobile hotspot from being turned off automatically.



3. Open AVerTouch. A white camera card will be displayed when your document camera is detected.



4. Click the **Connect** button .
5. Choose **Hotspot** from the **Connection mode** drop-down list in the **Connect to a Wi-Fi Network** dialog box. Click **Done**.

Connect to a Wi-Fi network

Please select the Wi-Fi and set your camera name and password

* Connection mode
Hotspot

* Select Wi-Fi network
DA0000591_hotspot

* Camera name
AVerVision M15W

Camera passcode
Camera passcode (optional)


Leave blank to keep default settings. You can come back and change this later if you want.

In "Hotspot" mode, AVerTouch will turn on the PC hotspot.


Cancel Done

Connect Your Document Camera on iPadOS12

1. Open iPad Wi-Fi settings and look for document camera names such as “AVerM15W-*****” and “AVerM70W-*****”.
2. Select a document camera to connect.



3. Open AVerTouch. A white camera card will be displayed when your document camera is detected.




4. Click the **Connect** button  to connect and follow the instruction.
5. A notification will take you to iPad Wi-Fi settings to select your Wi-Fi network.
6. Open AVerTouch again. A purple camera card will be displayed.




Upgrade Document Camera Firmware

To upgrade your document camera firmware:


1. Click the **Camera information** button .




2. When new firmware is available, a **New** button  **New** is displayed. Click **New**.



3. Click **Start** and follow the instructions.



Live View Interface



1. Home

Return to the Cameras page.

2. Fly-Out Media Library

Open your local AVerTouch media library or Google Drive. Drag and drop your files to the live view screen or add up to 2 cameras to view in a split screen of up to 4 sections.

3. Bottom Toolbar


Offer various tools for editing the live view image. The toolbar's items can be customized in **Camera Settings**  > **Display > Toolbar**.

4. Right Toolbar

Provide functionalities for controlling the live view settings, such as split screen, widget mode and optical character recognition (OCR).

5. Camera Settings

Adjust camera settings.



• Camera

Item	Description
Set all Adjustments to Auto	Toggle to manually adjust brightness, contrast and exposure.
Resolution	Change the resolution.
Mirror	Toggle to flip the image horizontally
Camera Mode	Choose among normal, motion or high quality.
Image Frequency	Choose between 50Hz and 60Hz.

• Display

Item	Description
Toolbar	Show or hide toolbar items.
Display Timer	Toggle to show a timer over the top of the live view.

• Record

Item	Description
File Format	Choose video and image formats.

• Network

Item	Description
Wi-Fi Setting	Set up a Wi-Fi connection with a USB cable.
Network bandwidth	Choose network bandwidth.

Toolbars

Bottom Toolbar


Item	Descriptions
 <p data-bbox="172 349 349 371">Google Classroom</p>	<p data-bbox="393 300 1036 354">Teachers can use these tools to add materials to assignments, such as images and videos and give feedback:</p> <ul data-bbox="393 359 1036 564" style="list-style-type: none"><li data-bbox="393 359 1036 429">•  Screenshot: Take a screenshot and click Assign to upload it as assignment.<li data-bbox="393 429 1036 499">•  Record: Record a video and click Assign to upload it as assignment.<li data-bbox="393 499 1036 564">•  Assignment list: Teachers can give feedback and see submission history of an assignment. <p data-bbox="393 612 449 635">Note:</p> <ul data-bbox="393 644 1036 740" style="list-style-type: none"><li data-bbox="393 644 1036 676">• Make sure you have a class in Google Classroom.<li data-bbox="393 676 1036 740">• Log in with your Google account and select all checkboxes to allow AVerTouch access.
 <p data-bbox="172 804 237 826">Freeze</p>	<p data-bbox="393 751 586 774">Freeze the live view.</p>
 <p data-bbox="172 903 271 925">Annotation</p>	<p data-bbox="393 850 983 904">Use any of the following tools to mark up the live view, provide feedback or pinpoint in detail:</p> <ul data-bbox="393 914 1036 1455" style="list-style-type: none"><li data-bbox="393 914 1036 984">•  Select window: Click to stop annotating so you can access other functions on screen, such as the widget mode.<li data-bbox="393 984 1036 1054">•  Select object: Drag to select one or more annotations, then drag them where you want.<li data-bbox="393 1054 1036 1125">•  Pen: Change the pen color and thickness, then draw a shape.<li data-bbox="393 1125 1036 1195">•  Highlighter: Change the highlight color, thickness and opacity, then draw the highlight.<li data-bbox="393 1195 1036 1265">•  Line: Change the line color, style and thickness, then draw a line.<li data-bbox="393 1265 1036 1335">•  Text: Change the font color and style, type your text, then drag the text box where you want.<li data-bbox="393 1335 1036 1406">•  Shape: Select a shape color and style, then drag a shape.<li data-bbox="393 1406 1036 1476">•  Eraser: Click the eraser button, then select an annotation you want to delete.<li data-bbox="393 1476 1036 1455">•  Clear all: Click to clear all annotations.

 <p>Screenshot</p>	<p>Take a screenshot. Screenshots are stored to your local AVerTouch Media Library or Google drive.</p>
 <p>Record</p>	<p>Use these tools to record videos:</p> <ul style="list-style-type: none">  Microphone: Mute or unmute the microphone.  Camera record: Record the camera live view.  Screen record: Record the desktop. <p>Videos are stored to your local AVerTouch Media Library or Google drive.</p>
 <p>Snipping</p>	<p>Drag the square over the area you want to capture, then drag the gray handle to change the size. Click Capture to save the image.</p>
 <p>Focus</p>	<p>Focus automatically or manually.</p>
 <p>Rotate</p>	<p>With each click, rotate the live view 90 degrees counterclockwise.</p>
 <p>Presentation Tools</p>	<p>Highlight your content using these tools:</p> <ul style="list-style-type: none">  Spotlight: Create a spotlight effect. Drag the edge of the shape to change the size. To change the shape and transparency, click the menu button .  Visor: Drag to raise or lower the visor to cover part of the information. To change the transparency, click the menu button .
 <p>Zoom/Panning</p>	<p>Use these tools to pan, tilt and zoom:</p> <ul style="list-style-type: none">  Area zoom: Drag the square to the area you want to magnify, then drag the gray handle to change the size. Pan, tilt and zoom: AVer document cameras typically use digital zoom. You can zoom in or out. Or zoom in, then pan and tilt inside the zoomed image.
 <p>Hide/Show Toolbar</p>	<p>Hide or show toolbar.</p>
 <p>Google Lens</p>	<p>Capture images to search on Google, or use Google Lens to identify text for reading aloud translating into other languages.</p>

 <p>Keystone Correction</p>	<p>Automatically or manually adjust the distorted image to make it appear rectangular and aligned.</p> <ul style="list-style-type: none"> • Click Save to capture images and save to AVerTouch local media library. • Enable Manual Crop to use your mouse to resize the capturing area. • Go to AVerTouch local media library and double-click on the images to check the final results after keystone correction.
---	--


Right Toolbar

Item	Descriptions
 <p>Hide/Show Toolbar</p>	<p>Hide or show toolbar.</p>
 <p>Camera Select</p>	<p>Use these tools to switch between AVer camera live views or select picture-in-picture (PIP) mode:</p> <ul style="list-style-type: none"> •  AVer Camera: Select a camera you want to switch to. •  Picture-in-picture (PIP) Camera: Select a camera for the smaller live view. You can resize and drag it where you want.
 <p>AI Functions</p>	<p>Highlight your content using these tools:</p> <ul style="list-style-type: none"> •  AI Image Generator: Please refer to <AI Image Generator> for more details. •  Super Resolution: Sharpen and magnify the selected part of an image. Drag the square to the area you want to sharpen, then drag the gray handle to change the size. To adjust, click the Area select button .
 <p>Split Screen</p>	<p>View images, videos or camera live views in a split screen of up to 4 sections. For details, please refer to <Split Screen and Fly-Out Media Library>.</p>
 <p>Widget Mode</p>	<p>Turn AVerTouch into a widget. You can drag it where you want, resize it and use these tools to control your document camera:</p>

	 <ul style="list-style-type: none"> •  Camera control: Show more tools, including zoom in, zoom out, zoom reset, freeze and rotate. •  Desktop Screenshot: Take a screenshot of the desktop. •  Camera Screenshot: Take a screenshot of the camera. •  Record: Record videos. •  Hide: Hide the live view.
 <p>Optical Character Recognition (OCR)</p>	<p>Convert an image of text into a searchable PDF file, editable Word file and more. For details, please refer to <Optical Character Recognition (OCR)>.</p>

Split Screen and Fly-Out Media Library


- Split the live view screen into 2, 3, or 4 sections.
- You can add up to a mixture of 2 AVer document cameras and third-party webcams in a split screen.




To view in a split screen:

1. Click the **Split Screen** button  on the right tool bar or the **Media Library** tab  will both open the fly-out Media Library.
2. To add images or videos in your local AVerTouch Media Library or Google drive, select the relevant tab on the top menu, then drag and drop your files to the live view screen. You can also select the files, then click the **Add File** button  on the bottom of the library.
3. To add up to a mixture of 2 AVer document cameras and third-party webcams, click the **Add Camera** button  on the bottom of the library, then select your camera.
4. You can also click the **Shuffle** button to shuffle the layout.

- Click a section to select, then use the toolbar to focus, zoom, rotate and enter full screen. Click the **X** button on the toolbar to close the section.




- In split screen, you can also use the bottom toolbar to annotate, take screenshots, record, and more. Click the **Show Toolbar** button  in the lower right corner to show the toolbar.



- To close the split screen and return to the live view, click the **X** button in the upper left corner of the window.

Optical Character Recognition (OCR)

- AVerTouch offers a 30-day free trial or a limited 500-image trial. The free trial will end after 30 days have been reached or all 500 images are used, whichever comes first.
- You can purchase or activate your license via the OCR free trial pop-up window or Account page. Make sure your computer has internet when purchasing and activating your license.
- OCR is available on Windows only and supports AVer USB document cameras. Make sure your document camera is connected to a computer with a USB cable.




System Requirements:

- Windows 7, 10, 11
- Processor: Intel Core i3 or above
- Hard disk space: 2 GB
- RAM: 4 GB
- Resolution: 1366 x 768 or higher
- USB 1.1 or above to connect AVer document camera to a computer

To scan with OCR:

1. Click the **OCR** button  on the right toolbar. First-time users will see an OCR free trial pop-up window. To start the free trial, click **Start your trial**. To purchase or activate your license, click **Enter license**.



2. Adjust your image of text using these tools:
 - Bottom toolbar: Pan, tilt, zoom, focus, rotate or adjust brightness and contrast.
 - Top menu:
 - Scan Mode: Scan a single page or multiple pages.
 - Export Format: Select a format.
 - Language Identification: Select the language of your text.
 - Manul Crop: Drag the gray handle to resize the blue square.
 - Auto Page Orientation: Rotate automatically based on text orientation.
 - Edge Fill: Fill missing corners and edges.
3. To scan a single page, click **Export**. To scan multiple pages, click **Capture** after each page, then click **Export** when you have finished scanning.
4. Your scanned files will appear under the OCR tab in the fly-out Media Library.
5. To close the OCR window and return to the live view, click the **X** button in the upper right corner of the window.

AI Image Generator

Use the AI function to describe images and generate prompts, or input prompts to create images. Capture images with connected AVer USB Document Cameras, select images from the AVerTouch media library, or input your own prompt.




System Requirements:

	Minimum Configuration	Recommended Configuration
Graphics Processing Unit (GPU)	GTX1050Ti	RTX3060Ti
Video RAM (VRAM)	4GB	8GB
Memory (RAM)	8GB	16GB
Storage	20GB, SSD is recommended	
Processor (CPU)	<ul style="list-style-type: none">Windows: Intel or AMD x86 processor.Mac: Apple M1 chip or later.	
System Version	<ul style="list-style-type: none">Windows: Windows 10 64-bit or above.Mac: MacOS 14.2 or above.	

To use AI Image Generator:


1. Click the **AI Functions** button  on the right toolbar, then click **AI Image Generator** . AVerTouch will verify your system requirements and prompt you to download AI Image Generator plugin if compatible.

2. Capture images using a connected AVer USB Camera and click **Describe** to generate a description. The process may take some time.



3. Once completed, the prompt will appear in the text box. You can edit the prompt, enter a new one, or copy/delete it. Click **Generate** to create a new AI image.
4. Drag the **AI Creativity** slider to adjust the generated results.
 - **Low Creativity:** Produces images closely aligned with the prompt, using predictable patterns and styles.
 - **Neutral Creativity:** Balances fidelity to the prompt with slight creative elements.
 - **High Creativity:** Generates diverse and imaginative images with unique styles and innovative details.
5. Click the **Save** button  to save the image in the AVerTouch local media library.

To use images in AVerTouch media library:




1. Click the **Image** button  to view images in the AVerTouch local media library. Drag and drop an image onto the main view.
2. Click **Describe** to generate a description for the image. Edit the prompt as needed and click **Generate** to create a new AI image. You can also copy or delete the prompt.
3. Drag the **AI Creativity** slider to adjust the generated results.
4. Click the **Save** button  to save the image to AVerTouch local media library.

Note:

For more information, click the **FAQ** button  to access the AVer FAQ webpage.

To input your own prompt:




1. Type a detailed description of the image you want to create in the **Prompt** text box.
2. Click **Generate** to create the image based on your prompt. The process may take some time.
3. Preview the created image. You may click the **Save** button  to save it to the AVerTouch local media library, or make adjustments if needed.

Troubleshoot

Rename files in the fly-out Media Library.

1. Select one of the following tabs where your file is stored: Image, Video, OCR, and Google Drive.



2. Click the **folder** button  to the right of the tabs to open that folder in File Explorer (Windows) or Finder (Mac).
3. Rename the file and close the folder.
4. Click the **sync** button  to the right of the tabs to see the renamed file.

Improve OCR result.


- Use the AVer scanning mat, if available, for the best scanning environment.



- High-quality images are key to having good OCR results. Make sure there is sufficient lighting and the image of text fills up at least 80% of the document camera's field of view.

Check OCR free trial status or OCR license key.

- Go to **Account > OCR License**.



How many computers can I activate my OCR license on?

- Your OCR license key can be activated on one computer at a time.
- To transfer your license key to another computer, first take note of your license key, deactivate it on the Account page on the old computer, then activate it on the Account page on the new computer.