AVer CP Series Quick Start Guide

Package Contents



- 1. Connect the power cord to power port (100V 240V, 50Hz/60Hz), then, plug into wall outlet.
 - 65"



75"/ 86"



2. Press rocker switch to enter standby status and the power indicator will turn to red.



3. Next, press the power switch (located on the front panel) or the power button on the remote control to turn on the interactive panel. If you have an OPS computer installed, it will turn on, too. The power indicator on the front panel turns green when the system is fully started.



4. The main display screen will be shown as below.





5. Input Source Selection:

The AVer CP supports a variety of input sources. Follow the steps below to select the different input sources.

- 1. Press **Source** on the remote control or press **Source** on the control panel of the interactive panel. Also, you can press **on the main screen to call out the input source page**.
- From the source page, use the ▲, ▼, ◄ or ► button on the remote control to select or use your finger to select directly on the screen.



6. Annotation:

On the main screen, select 🛄 (Whiteboard mode) to switch to Whiteboard mode. In Whiteboard mode,

select 📕 or 📕 to draw, write, and highlight on the screen.



OPS Installation

- 1. Insert the OPS into the special slot on the rear of the interactive panel.
- 2. Secure the OPS with screws and make sure the OPS is installed properly.



Wall Mount Installation

Dimension of the 4 bracket mounting holes



Ventilation distance



Software, FAQ, Training Videos

Download The AVer Interactive software, check out frequently asked questions, training videos please go to: http://averusa.com/classroom-technology/support/.

For detailed warranty information, please visit our website <u>http://www.averusa.com</u> and select the country where the unit is purchased.