

[Windows/MAC] CaptureShare Software Release Note – Aug 27th, 2021

VERSION	V1.3.2050.0
HARDWARE	The following product models are supported by CaptureShare.
COMPATIBILITY	DocCam: U50/U70/U70+/F17-8M/F50-8M/M17-13M/M15-13M/M11-8M/M90UHD/M15W /M70W/M5 Tracking cameras:
	 DL30 PTC500S/TR530/PTC115/TR320/TR333/TR331/TR313/TR311HN/TR311/TR310 (TR models V21 or later) PTZ310/PTZ310W/PTZ310N/PTZ330/PTZ330W/PTZ330N (PTZ models V66 or later)
OPERATING DEVICES / SYSTEMS	Win OS 7, Win OS 10 Mac 10.14 Mac 10.15 Mac 11

	- [WIN] Add audio virtual device support in virtual camera tool (64 bits OS only): Initial the UAC from the RTSP camera's microphone in virtual camera settings [WIN/MAC] Add more camera/tracking settings for DL30: Effective Tracking Area/Auto Zoom/Hybrid Mode/Auto WB mode switch - [WIN/MAC] Efficacy improvement for record function and previewing: Reduce the latency and system loading for the camera record function and previewing
V1.3.2050.0	BUG FIXED
Release date: Aug 27 2021	 [WIN] Capture and Record function failed happened by Antivirus software. [WIN] Show the Insufficient memory information in record function frequently. [MAC] The camera widget cannot be moved after adjusting the size (EX: Maximize window) or switching the camera source. [MAC] The zoom in/out bar in control panel shows in wrong position.
	- [WIN] Language change UI will not be affected instantly in virtual camera tool. Users need reopen the tool for new language display. We will fix it next release version.

	[WIN/MAC] UVC streaming display isn't workable with <ndi mode="" only="" streaming="">, but users still can select it in the list includes 3rd party Software.</ndi>
Known issues	 We are working on the fix for next release. Workaround: Please change the camera mode to "USB only".
	Camera 4K resolution only can be selected in USB only mode.
	Workaround: Switch the mode from others to "USB only" mode in web settings.

Limitation	 [WIN] Users can set the virtual camera while camera is on USB only mode. When users start to use virtual camera, they need switch the mode to USB + streaming or streaming only mode in order to get the video source. [WIN] Virtual camera tool only support video source in windows system. Cannot establish the audio source. [WIN] Virtual camera video source cannot be used in UWP (Universal Windows Platform) app. [WIN/MAC] DL/PTZ/TR camera models don't have the brightness settings in

VERSION	V1.3.2046.0 (MAC) V1.3.2047.0 (WIN)
HARDWARE	The following product models are supported by CaptureShare.
COMPATIBILITY	DocCam: U50/U70/U70+/F17-8M/F50-8M/M17-13M/M15-13M/M11-8M /M90UHD /M15W
	/M70W
	PTZ and Tracking cameras:
	- DL30
	- Tracking cameras: TR331/333/TR313/TR311/TR311HN/TR310 (TR models Firmware
	V21 or later)
	- PTZ cameras: PTZ310/PTZ310W/PTZ310N/PTZ330/PTZ330W/PTZ330N (PTZ models
	V66 or later)
	- PTC500S/TR320/TR530 (Virtual USB only)
OPERATING	Win OS 7, Win OS 10
DEVICES /	
SYSTEMS	Mac 10.14 Mac 10.15

	WHAT'S NEW & Improvement
V1.3.2046.0 (MAC)	 [WIN] Virtual camera tool feature added: If you have any of the above supported PTZ and Tracking cameras, now you can control and stream the camera to the CaptureShare software as through the camera is locally connected via USB. The only requirements are that these camera must be put on the same VLAN as the PC/MAC running the CaptureShare software.
V1.3.2047.0 (WIN)	BUG FIXED
Release date: June 3rd 2021	 [WIN] Audio source drops after setting click track on DL30 camera. [WIN] The frame for Click track sometimes disappears or has wrong status displayed. [MAC]The camera widget cannot be moved after adjusting the size (EX: Maximize window) or switching the camera source. [MAC]The zoom in/out bar in the control panel showed in the wrong position.
	- [WIN]In virtual camera tool setting, no error message while users typed in the wrong

account or password.

Known issues [WIN/MAC]	[Win/MAC] UVC streaming display isn't workable with <ndi mode="" only="" streaming="">, but users still can select it in the list includes 3rd party Software. O We are working on the fix for next release. O Workaround: Please change the camera mode to "USB only". Camera 4K resolution only can be selected in USB only mode. O Workaround: Switch the mode from others to "USB only" mode in web settings.</ndi>
Limitation	 [Win] Users can set the virtual camera while camera is on USB only mode. When users start to use virtual camera, they need switch the mode to USB + streaming or streaming only mode in order to get the video source. [WIN] Virtual camera tool only support video source in windows system. Cannot establish the audio source. [WIN] Virtual video source cannot be used in UWP (Universal Windows Platform) app. [WIN/MAC] DL/PTZ/TR camera models don't have the brightness settings in CaptureShare. It can be adjusted in web settings.

VERSION	V1.3.2043.0
HARDWARE	The following product models are supported by CaptureShare.
COMPATIBILITY	DocCam: U50/U70/U70+/F17-8M/F50-8M/M17-13M/M15-13M/M11-
	8M/M90UHD/M15W/M70W
	Tracking cameras: TR333/TR313/TR311/TR310 (TR models Firmware V21 or later)
	PTZ cameras: PTZ310/PTZ310W/PTZ310N/PTZ330/PTZ330W/PTZ330N (PTZ models V66 or
	later)
OPERATING	• Win OS 7, Win OS 10
DEVICES /	• Mac 10.14 Mac 10.15
SYSTEMS	

V1.3.2037.0	WHAT'S NEW
Release date: November 06, 2020	 Supports AVer DL30 camera (pre-release). Supports AVer PTZ cameras. Supports new functions: Sleep Mode/Profile in settings for DL30 (pre-release). Displays network & device information while connecting the DL30 (pre-release) via USB cable. *IP Address/ Serial number / Mac address / FW version
	BUG FIXED - Zoom in/out setting should be reset to default value after clicking home button.

- Crash happens if user connects two tracking cams at the same time. Random issue.
- Firmware update function should be disable for some models which cannot support firmware upgrade function. [MAC Only]

KNOWN ISSUES (Win/MAC)

- UVC streaming display isn't workable with <NDI/Streaming only mode>, but users still can select it in the list. A fix is being released for next release. Workaround: Please change the camera mode to "USB only".
- Camera 4K resolution can only be selected in USB only mode.
 - O Workaround: Switch mode to "USB only" mode in the web setting.
- PTZ/TR/DL camera models don't have the brightness settings. It cannot be used in some modes and need adjust it in web settings. Working on a fix for next release.
- Tracking sensitivity cannot be used in Zone mode.

VERSION	V1.3.2037.0
HARDWARE COMPATIBILITY	The following product models are supported by CaptureShare. DocCam: U50/U70/U70+/F17-8M/F50-8M/M17-13M/M15-13M/M11- 8M/M90UHD/M15W/M70W Tracking cameras: TR333/TR313/TR311/TR310 (TR models Firmware V21 or later)
OPERATING DEVICES / SYSTEMS	 Win OS 7, Win OS 10 Mac 10.14 Mac 10.15

V1.3.2037.0 **WHAT'S NEW** Release date: Supports AVer tracking camera. (TR models) November 06, Supports camera tracking control, and preset settings via UVC. (TR models) 2020 Supports CaptureShare functions (Recording/Streaming/Capture) for TR models. To access the Camera control tool for PTZ camera control, navigate to the "AVer Information Inc" folder and select the "AVerCamera Setting Tool". AVer Information Inc AVer IPCam Utility **AVer PTZ Management** AVerCam Firmare Update AVerCam Setup AVerCamera Setting Tool **BUG FIXED**

N/A (First release version for AVer TR models)

KNOWN ISSUES (Win/MAC)

- UVC streaming display isn't workable with <NDI/Streaming only mode>, but users still can select it in the list. A fix is being released for next release. Workaround: Please change the camera mode to "USB only".
- Camera 4K resolution can only be selected in USB only mode.
 - O Workaround: Switch mode to "USB only" mode in the web setting.
- PTZ/TR camera models don't have the brightness settings. It cannot be used in some modes and need adjust it in web settings. Working on a fix for next release.
- Crash happens if user connects two tracking cams at the same time. Random issue. Working on a fix for next release.

KNOWN ISSUES (MAC Only)

 424x240 resolution cannot be displayed with broken images. Working on a fix for next release.