

[Windows/macOS] AVer PTZ Link Software Release Notes – Apr 1, 2022

VERSION	V1.3.1025.0
HARDWARE	The following product models are supported by AVer PTZ Link.
COMPATIBILITY	• TR310/TR311/TR311HN/TR313/TR331/TR333 V0.0.0000.21 or above,
	• TR530/TR320 V0.0.1000.47 or above,
	• PTZ310/PTZ310N/PTZ330/PTZ330N V0.0.0000.56 or above,
	• TR313V2 V0.1.0000.18 or above,
	• TR333V2 V0.1.0000.23 or above,
	• DL30 V7.0.0022.28 or above
OPERATING	Windows® 7, 8.1, 10, 11
SYSTEMS	macOS 10.14 or above

V1.3.1025.0	New Features	
Release date:	1. Supports the Yamaha RM-CG ceiling array n	nicrophone;
April 1 st , 2022	2. Supports the Shure MXCW series;	
	3. Support for up to 128 channels within one g	group on PTZ Link;
	Microphone Camera	Human tracking 👔
	Channel 121 Please select camera preset	Off
	Channel 122 Please select camera preset	Off 🗸
	Channel 123 Please select camera preset	Off
	Channel 124 Please select camera preset	Off
	Channel 125 Please select camera preset	Off
	Channel 126 Please select camera preset	Off
	Channel 127 Please select camera preset	Off
	Channel 128 Please select camera preset	Off


4.	Support for "Human	Tracking" on/off on P	TZ Link(*Premi	um only)	
	Microphone	Camera		Human trackir	ng 🚯
	Channel 1	Preset 0	~	Off	~
	Channel 2	Preset 0	~	Off	~
5.	Support for manual i	nput of "time to go ba	ack to Preset 0"	;	
	Time to trigger Pre 1 sec Value for time to g On 0 6 Minutes minimum Seconds minimum Seconds maximum Cancel	o back to Preset 0			
Im	provements				
1.	Lowered the video lat	ency when using Virtu	ial Camera on P	TZ Link. (Curr	rent video
	latency: local 200 ms)				
2.	Fixed the issue that vi	rtual Camera might fre	eeze if camera e	experienced r	reconnection
	during streaming.				
3.	Support for online use	er manual directly acce	essible from Set	tings/Help Co	enter.

🛞 AVer PTZ Link informatio	on	\times	
System	User Manual	Read	
License			
Help Center			
About			
Privacy Policy			
Known Issues			
1. When connecting F	PTZ Link with Sennheiser TCC2, PT	Z Link may still ca	pture the channel
8(Azimuth 315°) wh	en feeding a far-end signal into TC	C2 via Dante.	
• This will be fi	xed in the next version.		

VERSION	V1.3.1021.0
HARDWARE	The following product models are supported by AVer PTZ Link.
COMPATIBILITY	• TR310/TR311/TR311HN/TR313/TR331/TR333 V0.0.0000.21 or above,
	• TR530/TR320 V0.0.1000.47 or above,
	• PTZ310/PTZ310N/PTZ330/PTZ330N V0.0.0000.56 or above,
	• TR313V2 V0.1.0000.18 or above,
	• TR333V2 V0.1.0000.23 or above,
	• DL30 V7.0.0022.28 or above
OPERATING	Windows® 7, 8.1, 10, 11
SYSTEMS	macOS 10.14 or above

V1.3.1021.0	New Features	
-------------	--------------	--

Release date:	1.	Support for USB connection (*WIN OS only) with camera (Premium version);
February 18, 2021		Connect Camera via USB Connect Camera via USB
	2.	Support for virtual camera through USB connection (*WIN OS only);
		Link more devices + Select your device Meeting room B Meeting room B Aver TR311HN Mic Meeting room D Mic Meeting room B Aver TR311HN Mic
		Virtual camera is sent to the third party program. Virtual camera is enabled.
		(*NOTE: The camera icon will be BLUE and equipped with a blinking dot when virtual
		camera is enabled and sent to third party program.)
	3.	Support for subscription of virtual camera which includes key code and 60-day free
		trial;



	Known Issues
:	1. Virtual Camera may freeze if camera(s) experiences reconnection during
	streaming.
	• Issue can be resolved by restarting PTZ Link software (This bug will be
	fixed in the next release of PTZ Link.)
:	2. User may notice a certain video latency when using the Virtual Camera of PTZ Link.
	• This latency issue will be optimized in the next release of PTZ Link.

VERSION	V1.1.1013.0
HARDWARE	The following product models are supported by AVer PTZ Link.
COMPATIBILITY	· TR310/TR311/TR311HN/TR313/TR331/TR333 V0.0.0000.21 or above
	· TR530/TR320 V0.0.1000.47 or above
	• PTZ310/PTZ310N/PTZ330/PTZ330N V0.0.0000.56 or above
	· TR313V2 V0.1.0000.18 or above
	· TR333V2 (* Early Q1 2022)
	· DL30 V7.0.0022.28 or above
OPERATING	Windows [®] 7, 8.1, 10, 11
SYSTEMS	macOS 10.14 or above

V1.1.1013.0	New Features
Release date:	6. Added support for the AVer DL30.
December 6, 2021	7. Confirmed compatibility with Windows [®] 11.
	Bug Fixes 1. Modified some values to lower the possibility of random software crashes.
	Known Issues
	1. When more than one channel is detected, camera is not able to support group
	framing.
	• In most meetings and a lot of online classes, conversations go back and forth.
	Sennheiser TeamConnect Ceiling 2 might pick up speakers' voices from all around
	the room, causing the camera to go back and forth between different preset
	points. If such is the case, you can enable the Priority Zone of Sennheiser
	TeamConnect Ceiling 2 so that it only picks up the audio signals of the zone you
	chose. For details on the Priority Zone of Sennheiser TeamConnect Ceiling 2, visit:
	Setting up Zones for TeamConnect Ceiling 2 (sennheiser-sites.com)
	• As for Shure, the second channel only will be detected once the previous speaker
	stops talking.

VERSION	V1.1.1012.0
HARDWARE	The following product models are supported by AVer PTZ Link.
COMPATIBILITY	• TR310/TR311/TR311HN/TR313/TR331/TR333 V0.0.0000.21 or above,
	· TR530/TR320 V0.0.1000.47 or above,
	• PTZ310/PTZ310N/PTZ330/PTZ330N V0.0.0000.56 or above,
	· TR313V2 V0.1.0000.18 or above

OPERATING	Windows® 7, 8.1, 10
SYSTEMS	macOS 10.14 or above
V1.1.1012.0	New Features
Release date:	8. Added support for "Sennheiser TeamConnect Ceiling 2" microphone
September 27, 2021	9. Added support for AVer TR313V2 series
	Bug Fixes
	1. Resolved the issue of not supporting macOS 11, this limitation has been fixed.
	2. Resolved the issue of not able to turn on PTZ Link when PC is under 4k resolution,
	this bug has been fixed.
	3. Resolved the issue of unsynchronized indication while microphone is disconnected.
	Known Issues
	2. When more than one channel is detected, camera is not able to support group
	framing.
	· In most meetings and a lot of online classes, conversations go back and forth.
	Sennheiser TeamConnect Ceiling 2 might pick up speakers' voices from all around
	the room, causing the camera to go back and forth between different preset
	points. If such is the case, you can enable the Priority Zone of Sennheiser
	TeamConnect Ceiling 2 so that it only picks up the audio signals of the zone you
	chose. For details on the Priority Zone of Sennheiser TeamConnect Ceiling 2, visit:
	Setting up Zones for TeamConnect Ceiling 2 (sennheiser-sites.com)
	• As for Shure, the second channel will only be "activated/detected" once the
	previous speaker stops talking.

General
This release note is only for the announcement of newly supported models that have
been fully tested on PTZ Link V1.1.1009.0; Therefore, no exclusive software release is
needed.
New Features
1. The following microphone systems are tested and supported by current release
version.
Shure MXA710 microphone
Shure MXA310 microphone
*Please note it's a requirement to set up and configure channels for MXA710 on Shure
Designer software first, so PTZ Link can work properly.
*Please note using a single channel on the MXA310 is not supported by PTZ Link. To
operate PTZ Link normally, please add and configure other channels on the MXA310
webpage.
Bug Fixes
The same as previous release note that published on May 11.
Known Issues
The same as previous release note that published on May 11.

V1.1.1009.0	New Features
Release date:	1. The following microphone systems are supported current release version.
May 11, 2021	Shure IntelliMix [®] P300 processor
	Shure MXA910 microphone

2. Able to link AVer cameras to maximum 5 sets of microphone systems.
3. Able to pair up camera preset points with up to 8 microphone channels.
4. Able to show camera and microphone status.
5. Able to configure time to trigger camera to go to preset points that already set up.
6. Able to configure time to go back to Preset 0 when no microphone channel is
detected.
7. Able to support English and Traditional Chinese version of the software.
Bug Fixes
None. Initial release.
Known Issues
1. When more than one channel is detected, camera is not able to support group
framing. (*Will support in the next version.)
2. MacOS lower than ver. 14 currently not supported. MacOS 11 will be added to
support list in the next version.